Contents

About This Manual xi
Field Test Support xiii

Part I CM-5 System Administration

Chapter 1 Introduction to the CM-5 System 5

1.1 Hardware Components 5
1.1.1 Network Hardware 6
1.1.2 Processing Nodes 8
1.1.3 Control Processors 9
The System Control Processor 9
1.1.4 I/O Devices 10
Scalable Disk Array (SDA) 12
DataVault 13
Integrated Tape System 13
CM5-HIPPI and CM-HIPPI 13
VMEIO Host Computer 14
CM-IOPG 14
1.2 CMOST Software 14
1.3 Job Management Systems 16

Chapter 2 CM-5 and Scale 3 System Startup Procedures 19

2.1 Powering Up a CM-5 System 22
2.1.1 Boot External Control Processors 22
2.1.2 Power Up All Peripherals 22
2.1.3 Power Up the CM-5, Including Its SDA 22
Powering Up a Network Cabinet 24
Powering Up a Device Cabinet 24
2.2 Powering Up a Scale 3 System, Including Its SDA 28
2.3 Check the Environmental Sensor Board's Status Panel 30

Copyright © 1995 Thinking Machines Corporation

2.4 Update the System Files 31
2.4.1 Ensure that hardware.install Is Correct 31
The **jtag_server** and **cmsa_server** entries 32
Entries Specific to the CM-5E 33
2.4.2 For CM-5 (Other than Scale 3) Sites Only: Update **io.conf** if CMIO Bus Device Configuration Has Changed 34
2.4.3 Systems with an SDA 34
2.5 Prepare for CM-5 Partitioning and for SDA Bringup 35
2.5.1 Log In to the System Control Processor 35
2.5.2 Set the **CMDIAG_PATH** Environment Variable 36
2.5.3 Start **cmsa-server** 37
2.5.4 Reset the CM-5 and Individual CP Network Interfaces 37
2.6 For CM-5 (Other than Scale 3) Sites Only: Initializing the CMIO Bus System 38
2.7 Bringing Up an SDA 39
2.7.1 Cold Boot the SDA 39
2.7.2 Download the SDA Configuration Information and Bring the Logical Device(s) On-Line 40
2.7.3 Check and Mount Each File System on Its IOCP 43
Optional: Using **/etc/fstab** 44
2.7.4 Reset Each PM's Network Interface 45
2.7.5 NFS-Mount Each File System 46
Optional: Using **/etc/fstab** 46

Chapter 3 Partition Management **49**

3.1 How Does Partitioning Work? 49
3.1.1 The Partitioning Commands 50
3.1.2 The Partitioning Rules 51
3.1.3 The **cmpartition** Prerequisites 53
3.2 Bringing Up a Partition 54
3.2.1 Viewing the Currently Configured Partitions: **cmpartition list** 54
3.2.2 Creating a Partition: **cmpartition create** 55
Executing **cmpartition create** 57
3.2.3 Activating a Partition: **cmpartition start** 59
Executing **cmpartition start** 60
Starting the Timesharing Daemon (**ts-daemon**) 61
3.3 Bringing Down a Partition 64
3.3.1 Deactivating a Partition: **cmpartition stop** 65
Executing **cmpartition stop** 65

Copyright © 1995 Thinking Machines Corporation

3.3.2 Deleting a Partition: **`cmpartition delete`** 66
Executing **`cmpartition delete`** 67

Chapter 4 Emergency and Non-Emergency Shutdown **69**

4.1 Shutting Down a CM-5 Other than a Scale 3 69
4.1.1 Shutting Down the CM-5 in an Emergency 69
4.1.2 Shutting Down the CM-5 in Situation Normal 75

4.2 Shutting Down the Scale 3 78
4.2.1 Shutting Down the Scale 3 in an Emergency 78
4.2.2 Shutting Down the Scale 3 in Situation Normal 79
4.2.3 Powering Off Only Part of the Scale 3 82

Chapter 5 CM Error-Logging System **83**

5.1 Implementing CM Error Logging 83

5.2 Error Message Description 84

Chapter 6 Preventive Maintenance **87**

6.1 Reviewing Operating System Error Logs 88

6.2 Reviewing I/O Device Error Logs 89
6.2.1 Dumping and Clearing SDA Logs 91

6.3 Monitoring the Environment Sensor Board's Status Panel 92

6.4 Weekly Test Procedure 95
6.4.1 Initial Conditions 95
6.4.2 Procedure Steps 95

Chapter 7 Accounting on the CM-5 System **99**

7.1 Overview 99
7.1.1 What Can CM-5 Accounting Do? 99
User Verification 100
7.1.2 What Does CM-5 Accounting Not Do? 100
7.1.3 How Does CM-5 Accounting Work? 100
Process Accounting 101
I/O Accounting 102
7.1.4 What Information Is Accounted? 103

7.2 Error Handling 109

7.3 Using the System 110

Copyright © 1995 Thinking Machines Corporation

7.3.1 **cmacct** Syntax 110
7.3.2 Obtaining Information About the Accounting System's Current State 112
7.3.3 Starting and Tuning the Accounting System 113
Starting Accounting 113
Tuning Accounting 114
7.3.4 Rotating Accounting Files 115
7.3.5 Freeing Accounting Records for Reuse 115
7.3.6 Shutting Down Accounting 116
7.4 Obtaining Information from the Accounting Records 117
7.4.1 Printing Accounting Records 117
7.4.2 Obtaining Summaries for Billing or Resource Management . . 117

Chapter 8 What to Do If the Operating System (ts-daemon) Hangs or Crashes 123

8.1 Examine the **ts-daemon** Log 125
8.1.1 **ts-daemon** Log 125
8.2 Restart the **ts-daemon** with **-Q0** 126
8.3 Check for a Hardware Problem: Run **find-cm-error** 127
8.4 Check for a Software Problem 128
8.4.1 **dbx** the **ts-daemon** 128
8.4.2 **kpndbx** the PNs 129
8.4.3 **kpndbx** the IOBA 131
8.4.4 Run **cmdiag -p** 132
8.5 Now What? 132

Part II SDA Administration

Chapter 9 SDA Command Center 139

9.1 Overview 139
9.2 Invoking the SDACC Environment 140
9.3 SDACC Command Interfaces 141
9.3.1 The None Selection 141
9.3.2 The SDA Utility Commands Selection 142
9.3.3 The SDA Administrative Commands Selection 143
9.3.4 SDA Log Commands Selection 147

Copyright © 1995 Thinking Machines Corporation

9.3.5 SDA Diagnostics Environment Selection 149
9.3.6 The All Selection 149

Chapter 10 SDA Configuration Files 151

10.1 Description of **`sda.install`** 151
10.1.1 Creating **`sda.install`** 151
10.2 **`hardware.install`** 155
10.3 **`sda.parameters`** 155
10.4 **`/dev/sdaNa`** 156
10.5 **`/etc/exports`** 156

Chapter 11 Managing Logical Device Configurations 157

11.1 Introduction 157
11.2 Configuration Requirements and Guidelines 158
11.2.1 Restrictions 158
11.2.2 Recommendations 159
11.3 Creating and Modifying Logical Devices 160
11.4 Logical Drive Substitutions (Sparing) 164

Chapter 12 Running SDA Diagnostics 167

12.1 Introduction 167
12.2 Initial Conditions 168
12.3 Procedure Description 169
12.3.1 Invoking the SDACC Interface 170
12.3.2 Invoking the cmdiag Interface 171
12.3.3 Running the Desired Tests 171
12.3.4 Leaving the Diagnostic Environment 174
12.4 Requesting Technical Support 174

Chapter 13 Managing SDA Logs 177

13.1 Introduction 177
13.2 Controlling Error Log Filters 179
13.3 Reading and Clearing SDA Logs 182
13.4 How SDA Error/Trace Logs Are Selected for Control 183

Copyright © 1995 Thinking Machines Corporation

Chapter 14 Backing Up the SDA 185

14.1 Making a Backup Using a DataVault 185

14.2 Making a Backup Using Tape 186

Chapter 15 Healing the SDA 189

15.1 Heal Procedure:
Running **`sda_disk_util`** from an IOCP 190

15.2 Alternative Heal Procedure:
Running **`sda_disk_util`** from a PM 192

Part III CMIO Bus Device Administration

Chapter 16 Configuring CMIO Bus Devices 199

16.1 Overview of CMIO Bus Device Configuration 199

16.1.1 Station ID, Bus ID, and Arbiter Status Conventions 200

16.2 Configuring a DataVault 201

16.2.1 Executing **`dvcoldboot`** 201

16.2.2 Editing **`io.conf`** 203

To Install a DataVault Into the System 203

To Remove a DataVault from the System 204

16.2.3 Resetting the Time on the DataVault's MicroVAX 205

16.3 Configuring a CM-IOPG or a VMEIO Host Computer 206

16.3.1 Executing vioconfig 206

16.3.2 Editing **`io.conf`** 207

To Install a CM-IOPG or VMEIO Host Computer into the System 207

To Remove a CM-IOPG/VMEIO Host Computer from the System 208

16.4 Configuring a CM-HIPPI 208

Appendixes

Appendix A The CM-5 (Other than Scale 3) `hardware.install` File 211

A.1 Introduction 211

A.2 CM-5E Entries 212

Copyright © 1995 Thinking Machines Corporation

A.2.1 CM-5E: New **PN_Backplane** Entries 212
A.2.2 CM-5E: New **DR_Backplane** Entries 213
A.3 File Header (shaded area 1) 213
A.4 **CM_System** (shaded area 2) 213
A.5 System Name (shaded area 3) 217
A.6 **CM_Type** (shaded area 3) 217
A.7 **DR_Height** (shaded area 4) 217
A.8 **jtag_server** and **cmsa_server** (shaded area 4) 217
A.9 **PN_Type** (shaded area 5) 218
A.10 **Partition_Manager** (shaded area 6) 218
A.11 **PN_Cabinet** 0 (shaded area 7) 219
A.12 **PN_Cabinet** 1 (shaded area 8) 223
A.12.1 **IO_Backplane** 0 223
A.12.2 **SPI_Backplane** 3 223
A.12.3 **IO_Backplane** 7 224
A.12.4 **DR_Backplane** 8–9 226
A.12.5 **CN_Backplane** 10 226
A.13 **DR_Cabinet** (shaded area 9) 227

Appendix B The Scale 3 hardware.install File 231
B.1 Introduction 231
B.2 CM-5E Entries 233
B.2.1 CM-5E: New **DR_Backplane** Entries 233
B.2.2 CM-5E: New **PN_Backplane** Entries 233
B.3 **CM_System** (shaded area 1) 234
B.4 System Name (shaded area 2) 234
B.5 **CM_Type** (shaded area 2) 234
B.6 **DR_Height** (shaded area 3) 234
B.7 **jtag_server** and **cmsa_server** (shaded area 4) 235
B.8 **PN_Type** (shaded area 4) 235
B.9 **Partition_Manager** (shaded area 5) 236
B.10 **PN_Cabinet** 0 (shaded area 6) 236
B.10.1 **PN_Backplane** 0 236
B.10.2 **IO_Backplane** 1 237
B.10.3 **CPI_Backplane** 2 238

Copyright © 1995 Thinking Machines Corporation

Appendix C The `io.conf` File **243**

C.1 Editing the `io.conf` File 243
C.1.1 The `Channel_Board_Configuration` Module 244
C.1.2 The `IO_device_configuration` Module 246

Appendix D I/O Error Messages **249**

Appendix E cmacct.awk **259**

Appendix F How to Disable Core File Dumping **261**

Appendix G SDA File System Operations **263**

G.1 Constructing SDA File Systems: `sdafsmake` 263
G.2 Checking SDA File Systems: `sdafsck` 264
G.3 Report SDA File System Information: `sdafsdump` 264
G.4 Optimize SDA File System: `sdafsopt` 264
G.5 Randomize `cminode` Assignments: `sdafsirand` 264

Appendix H SDA Chassis Diagrams **267**

Appendix I SDA LED Descriptions **271**

Appendix J Manual Pages **277**

Index

Index **403**

Copyright © 1995 Thinking Machines Corporation