Index

This index uses **boldface** page numbers to indicate that the reference is to a figure.

Symbols

*Lisp, 15
`/dev/cmac`, 101
`/var/adm/messages`, 109

A

accounting, 99–121
  `CM_ACCOUNT_ID`, 100
  `cmacct`, 110
  daemon, 101, 110
  error handling, 109
  extract command, 117
  file rotation, 115
  include file, 104, 108
  memory allocation, 111
  post-processor (**`cmacct.awk`**), 259
  records, 101
    freeing, 115
    printing, 117
    structure, 104, 108
  shutting down, 116
  starting, 113
  status of, 112
  summary generation, 117
  tuning memory usage, etc., 114
active (partition state), 54
air-flow sensor, 92
allocated (partition state), 54
arbiter, bus, 200

B

backing up, SDA, 185–188
backplane, SDA, diagram, 268
batch. *See* NQS, DJM
boot
  CM-5 system, 22
  SDA, 39
bus arbiter, 200
bus ID, 200

C

C-Star. *See* C*
C*, compiler, 15
caddy (disk), SDA, 158
  component diagram, 270
  LEDs, **272**
circuit breaker, 24
  DataVault, *71*
  device cabinet, *72*
  network cabinet, *73*
  Scale 3, 78, *82*
clock speed, 37
CM File System. *See* DataVault
CM Fortran compiler, 15
CM Runtime System, 15
CM-5E, 5, 6, 8
  clock speed, 37
  `hardware.install entries`, 212
    for Scale 3, 233

Copyright © 1994 Thinking Machines Corporation

cm-errors.log, 83
CM-HIPPI, 13
  See also CM5-HIPPI
  power switch, *74*
  powering down, 76
CM-IOPG, 14
  configuring, 206–207
    vioconfig, 206
  power switch, *74*
  powering down, 76
CM/AVS, 15
CM_ACCOUNT_ID, 61
CM_NO_PN_CORE, 261
CM5-HIPPI. *See* CM-HIPPI; CM5-HIPPI System Administrator's Guide
cmacct, 110
cmacct.awk (**/usr/etc**), 259
CMAX, 15
cmdiag, for SDA diagnostics, 167–176
CMDIAG_PATH, 36
CMFS. *See* DataVault
CMFS_perror, table of messages, 249–258
CMIO bus, 11, 34
  device, configuration, 199–208
  initializing, 38
cmlog, 126
CMMD, 15
CMOST, 14
  commands, manual pages, 277
cmpartition create, 55
  syntax, 57
cmpartition delete, 67
cmpartition list, 54
cmpartition start, syntax, 60
cmpartition stop, syntax, 65
cmreset, 37
  invalid clock source error, 223
CMRTS, 15
cmsa-server, 37
  failure to start, 31
  hardware.install entry, 217
  with partitioning, 51
cmsa-server.log (**/var/adm**), 125
CMSSL, 15
cmtar, backing up SDA, 186
CMview, 15
CMX11, 15
cold boot, SDA, 39
configuration
  CM-IOPG, 206–207
  DataVault, **201**
  logical device (SDA), 158
  VMEIO host computer, 206–207
configuration file, 31
  DataVault, 202
  SDA, 151–156
context switching (swapping), 63
Control Network, 6
  in partition, 59
control processor, 9
  system, 9
core dump, 123
  disabling, 261
CP, 9
crash
  SDA, 88
  ts-daemon, 89
    debugging, 123–134

D

Data Network, 6
DataVault, 13
  backing up SDA, 185
  circuit breaker, *71*
  configuration file on MicroVAX, *202*
  configuring, 201–203
    CM system configuration file parameters, 204, 208
    dvcoldboot, 201
  file server computer, 13
  log, 89
  powering down, 69, 76
  resetting MicroVAX' time, 205
daylight savings time, 205
dbx, **ts-daemon**, 128
DC OK, monitoring, 93
debugging, 15
  ts-daemon crash, 126, 128

Copyright © 1994 Thinking Machines Corporation

device cabinet, 8
  circuit breaker, *72*
  hardware.install entries, 219
  power up, 24
Diagnostic Network, 7
diagnostics
  find-cm-error, 127
  preventive maintenance, weekly, 96
  SDA, 149, 167–176
Disk Storage Node, 12
Distributed Job Manager. *See* DJM
DJM, 16
DSN, 12
  in partition, 58
dumping core, 123
dv_coldboot.config (**/usr/local/etc/diag**), 202
dvcoldboot, 201
dvcp, backing up SDA, 185

E

environment variables
  CM_ACCOUNT_ID, 61
  CM_NO_PN_CORE, 261
  CMSA_SERVER, 217
  JTAG_SERVER, 217
environmental sensor board, 30
  description of, 92
error
  accounting system, 109
  invalid clock source, 223
  log, 83
    message description, 84
    SDA, 177
  message, I/O, 249
ethernet, 11
exportfs, 44
exports (**/etc**), 44, 156

F

FIFO, Data Network, 37
fifo, Data Network, 60
file system. *See* DataVault; SFS
find-cm-error, 127
frame grabber, 14
fstab, 44, 46

G

GNU, 15

H

hang, **ts-daemon**, 123–134
hardware problem, 127
hardware.install, 31
  CM-5 system, 211–230
    CM-5E entries, 212
    sample, **214**
  Scale 3 system, 231–242
    CM-5E entries, 233
    sample, 232
header file
  cmdev/cmiodev.h, 249
  cmsys/tsl.h, 126
  iop_error.h, 249
healing, SDA, 190–194
HIPPI. *See* CM5-HIPPI
HPPI. *See* CM5-HIPPI

I

I/O, error messages, 249–258
I/O backplane, hardware.install entries, 224
I/O device, 10
  See also SDA, ITS, DataVault, CM5-HIPPI, VMEIO, CM-IOPG
I/O processor, 58
include file, accounting, 104, 108
Integrated Tape System. *See* ITS
invalid clock source error, 223
io.conf, 31, 243–248
  DataVault configuration, 203
  sample, **247**
io_cold_boot, 38
IOBA, 11
  chassis, hardware.install, 224
  in partition, 58

Copyright © 1994 Thinking Machines Corporation

IOCP, 9
iop_sys_errlist.c, 249
ITS, 13
See also ITS System Administrator's Guide

J

job management. *See* NQS, DJM
JTAG library, 95
jtag_server, 217

K

kpndbx, 129

L

LED
environment sensor board, 92
panel, 22
SDA, diagrams, **272–276**
table of switch settings, 23
list, partition configuration, 54
log
error, 83
DataVault, 89
operating system, 88
SDA, 88, 90, 177
ts-daemon, 89
SDA, 147
timesharing daemon, 89
logical device
bringing on-line, 40
configuration, 158
creating and mounting, 43
error log, 90
modifying, 160

M

magnetic indicator, environmental sensor board, 92
maintenance, preventive. *See* preventive maintenance
man pages, 277–377
manual pages, 277–377
memory
reducing CMOST memory overhead, 64
varying PN memory in partition, 63
messages (**/var/adm**), 88
mkdir, 43
mount, 44
mounting, NFS, soft (interruptible), 63

N

network, 6
network cabinet, 7
circuit breaker, *73*
hardware.install entries, 227
power up, 24
Network Interface, 6
Networking Queueing System. *See* NQS
NFS-mounting, SDA file system, 46
nfsd, 44
NFS-mounting, SDA file system, soft mounting (interruptible), 63
NFS-server non-response, 63
NI, 6
NQS, 16

O

on-line viewer, 15
overhead, reducing CMOST memory overhead, 64

P

parity disk, SDA, 158
parity group, SDA, 158
partition
activating, 59
bringing up, 54
components of, 49
creating, 55
deactivating, 65
deleting, 66
memory in, 56

Copyright © 1994 Thinking Machines Corporation

partitioning
rules for, 51
system requirements, 53
partitions.current, 56, 65
PM, 9
hardware.install entries, 218
PN, 8
pndbx, 15
power supply, monitoring, 94
powering down
CM-5 Scale 3 system
in an emergency, 78
in situation normal, 79
CM-5 system
in an emergency, 69
in situation normal, 75
CM-HIPPI, 76
CM-IOPG, 76
DataVault, 76
in an emergency, 69
SDA, in an emergency, 70
powering up, CM-5 system, 22
preventive maintenance
diagnostics, 96
schedule, 88
weekly procedure, 95
Prism, 15
processes, number of concurrent, 64
processing node, 8

Q

quantum, timesharing, 37, 60
queue, 16

R

reset, 37
rpc.mountd, 44
rules, for partitioning, 51

S

Scalable Disk Array. *See* SDA
Scalable File System. *See* SFS
Scale 3, 6
cabinet diagram, **239**, **240**, **241**, **242**
circuit breaker, 78, *82*
environmental sensor board, 92
hardware.install, 231–242
partition size, 51
powering down, 78
SCN, 12, 160
in partition, 58
master, 160
SCSI channel, SDA, **269**
SCSI Controller Node, 12
SDA
/var/adm/messages, 88
administration (sdacc), 143
backing up
to DataVault, 185
to tape, 186
bringup, 39
caddy (disk), 158
component diagram, 270
LEDs, **272**
chassis diagrams, 268
cminode, 264
cold boot, 39
configuration file, 151–156
crash, 88
diagnostics, 149, 167–176
disk initialization, 263
downloading configuration information, 41
error log, 90, 177–184
file system
checking, 264
creating, 43, 263
ID, 264
mounting, 43
NFS-mounting, 46
NFS-mounting, 63
obtaining information about, 264
optimizing, 264
healing, 190–194
LEDs, **272–276**
log, 147

Copyright © 1994 Thinking Machines Corporation

logical device
See also SDA, file system
bringing on-line, 40
configuration, 158
creating, 160
modifying, 160
parity disk, 158
parity group, 158
powering down
in an emergency, 70
in situation normal, 75
SCSI channel organization, **269**
SDA command center (**sdacc**), 139–150
sdacc, 139–150
sparing, 164
swapping, 63
SDA command center. *See* sdacc
sda.install, 31, 151
sda.parameters, 41, 155
sda_cold_boot, 39
sda_config, 39
sda_disk_util, 263
sdacc, 139–150
bringing logical device on-line, 40
controlling log filters, 179
reading/clearing logs, 90, 182
sdafs, 44
sdafsck, 43, 264
sdafsdump, 264
sdafsirand, 264
sdafsmake, 43, 263
sdafsopt, 264
sdaNa (**/dev**), 156
sensor
air flow, 92
temperature, 92
SFS, 12
See also SDA, file system
shutting down. *See* powering down
SNI, 37
sparing, SDA, 164
Star-Lisp. *See* *Lisp
startup
CM-5 system, 22
partition, 54
station ID, 200
status panel. *See* environmental sensor board
SunOS, 5
SuperSPARC, 8
swapping, 63
syslog, 83
syslog.conf, 83
system administration console, 9
system control processor, 9
system startup, 22

T

tape, backing up SDA, 186
tape I/O. *See* CM-IOPG; ITS
temperature, sensor, 92
time, setting on DataVault, 205
timesharing. *See* ts□daemon
timesharing daemon. *See* ts□daemon
trace. *See* log
ts-daemon
crash, 123–134
dbx'ing, 128
debugging mode, 126
hang, 123–134
disabling core file dumps, 261
log, 89, 125
logging bitmask, 126
stopping, 75
ts-daemon.log (**/var/adm**), 89, 125
ts-daemon
debugging mode, 64
memory overhead, 64
PN memory considerations, 63
quantum, context switching, 37, 60
starting on partition, 60, 61
swapping, 63
user verification, 61

U

user verification, 61

Copyright © 1994 Thinking Machines Corporation

V

VAX (**/usr/sys/config**), 205
Vector Unit, 8
verification, user, 61
vioconfig, 206
VME. *See* VMEIO host computer
VMEIO host computer, 14
  configuring, 206–207
    vioconfig, 206
vmunix, 14
VU, 8

X

X11, 15
X11R4, 15

Copyright © 1994 Thinking Machines Corporation