Part III

CMIO Bus Device Administration

Copyright © 1995 Thinking Machines Corporation

Part III of this manual describes the CMIO bus devices from a system administration perspective. It comprises one chapter:

- Chapter 16, "Configuring CMIO Bus Devices," explains how to configure the DataVault, VMEIO host computer, CM-IOPG, and IOBA (the CMIO bus's interface to the CM-5).

The following appendix also contains information about CMIO bus device administration:

- Appendix C, "The **`io.conf`** File," describes what this file is used for and how to edit it.

Copyright © 1995 Thinking Machines Corporation